

The Dual Wavelength UV Transmitter Development for Space Based Ozone DIAL Measurements




Task Leader: Dr. Narasimha S. Prasad

Technical Interchange Meeting

8/28 and 8/29

NASA Langley Research Center

Hampton, VA 23681



UV Wavelength Conversion Task

Laser Risk Reduction Program

Technical Lead : Dr. Narasimha S. Prasad



Overall Objective:

To develop efficient 1-micron to UV wavelength conversion technology to generate tunable, single mode, pulsed UV wavelengths of 320 nm and 308 nm

Performance Goals

Solid-state, conductively cooled, single longitudinal mode, output energy ≥ 200 mJ, pulsewidth ~ 25 ns and pulse repetition frequency of 50 Hz

Merits

High pulse energy allows enhanced performance during strong daylight conditions

Technical Approach


- The 532 nm wavelength radiation is generated by a 1064 nm Nd:YAG laser through second harmonic generation. The 532 nm pumps an optical parametric oscillator (OPO) to generate 803 nm. The 320 nm is generated by sum-frequency generation (SFG) of 532 nm and 803 nm wavelengths
- The hardware consists of a conductively cooled, 1 J/pulse, single mode Nd:YAG pump laser coupled to an efficient RISTRA OPO and SFG assembly-Both intra and extra-cavity approaches are examined for efficiency

Potential Applications

Space-based lidar operation for future NASA missions including atmospheric ozone profiling using Differential Absorption Lidar (DIAL) technique

Partners

Sandia National labs,
POC: Dr. Darrell Armstrong
Fibertek, Inc.,
POC: Dr. Floyd Hovis






Accomplishments



- Efficient, state-of-the-art, tunable, single longitudinal mode UV conversion technology using 1 micron wavelength pump source and novel nonlinear optics based technology has been developed for remote sensing of ozone from space-based platforms
- The Nd:YAG pump laser unit that generates $>1\text{J/pulse}$, 50 Hz PRF and $\sim 25\text{ ns}$ pulsewidth, with space qualifiable components and conforming to TRL 3 hardware has been built and tested
- Highly efficient nonlinear linear optics scheme to obtain UV wavelengths at $>200\text{ mJ/pulse}$ output energies has been demonstrated
- The developed UV converter scheme is a highly stable and reliable technique suitable for space based lidar operations
- A technical path to develop highly compact ($<2\text{ Cu. ft}$), rugged, UV transmitter technology for space environments has been identified




High Energy UV Transmitter


Technical Approach



- High energy low PRF is anticipated to provide high SNR under strong daylight conditions
- Basic Scheme comprises of a Nd:YAG laser pumped nonlinear optics based converter comprising of a second harmonic generation (SHG), optical parametric oscillator, (OPO) and sum frequency generation (SFG) processes



- The pump Laser is an upgrade of a ~300 mJ/pulse system built under NASA's Advanced Technology Initiative Program (ATIP)
- The UV converter hardware TRL = 3




Nd:YAG Pump Laser

-Technical Scheme to achieve 1 J/Pulse-




Final System Optical Configuration



Original ATIP Laser



Pump Laser Performance






Amplifier Modeling and Configuration



Modeling Results



Modeled output of dual 2-sided pumped and cooled amplifiers for 60 mJ input to first stage

Model is based on Franz-Nodvic result for a amplifying a square (in time) pulse

Model includes all key parameters explicitly

- Number of pump diodes (192)
- Peak diode power (75 W)
- Diode pulse width
- Input oscillator pulse energy (60 mJ)
- Input beam diameter
- Gain path length in amp
- Slab volume

Accounts for reduced gain for second pass

1 J per pulse output is predicted for 210 μs diode pump pulses

Amplifier modules


**3 Bounces-Rectangular
Shape-2 sided pumping in the
TIR axis, 2 sided conduction
cooling, Pump faces uncoated
(~10%loss)**

Dimensions
Incident Angle
Extraction
Aperture


Doping Level
Pump Diodes


6.8 x 13.0 x 75.3 mm³
Near Brewster (57°)
100% at full aperture
11.5 x 6.8 mm² (*internal*)
7.1 x 6.8 mm² (*external*)
0.5 ± 0.1 % Nd³⁺
192 ea. 50 watt QCW bars
(12 ea. 16 bar arrays)

2-Sided Pumped & Cooled Amplifier



Prototype Two-Sided Pumped and Cooled Head Design






Second Stage Amplifier Design Configuration




2-Sided Pumped Brewster Angle Slab Design Features

- | | |
|--|--|
| • Brewster angle design | Simplifies optical alignment, only single pass |
| • Mature technology | Reduces risk, based on synthesis of previously developed pump on bounce and Brewster angle designs |
| • Reduced tendency for parasitic oscillation | Parasitic control in Brewster slabs is well established |
| • Pump on bounce geometry | Allows good beam overlap with high gain regions with minimal diffraction effects |



Design is a synthesis of Brewster angle and pump on bounce approaches

Full Nd:YAG Laser Unit



- The dimensions of this laser unit, including a SHG module, is 34" x 22" x 8"
- With latest diode bars and modified opto-mechanical components, the above package can be reduced to less than a quarter of its size

Final System

Control and Power Electronics

Custom power supplies and control electronics for the upgrade have been built

- Control electronics consists of two 19" rack mountable boxes
- All power supplies are contained in two 19" rack mountable power supply modules
- Each amplifier can be individual set between high power and low power operation to allow the user to achieve a wide range of output powers at 50 Hz



Single Power Supply Module




Control electronics




Diagnostic Waveforms




Resonance Detection Photodiode, Oscillator Current, Preamp 1 Current, and Amp 1 Current Temporal Profiles in Low Power Mode




Resonance Detection Photodiode and RTP Modulator Drive Waveforms





Full System Results: Beam Profile & Typical Output Energy



Near field beam profile of final
amplifier output



Average power at 50 Hz of 51.0 W
(1020 mJ/pulse) for an input electrical
power to all pump diodes of 724 W

*1020 mJ/pulse and an electrical to optical efficiency >7% was achieved
with only 58 W peak power per diode bar pumping the amplifiers.*




Output Spatial Performance




20 W output near field profile

- Amplifiers 1 & 2 low power, amplifiers 3 & 4 high power
- X diameter 4.4 mm, Y diameter 5.5 mm




52 W output near field profile

- All amplifiers high power
- X diameter 5.2 mm, Y diameter 7.2 mm



Flat spatial profiles are required for efficient harmonic conversions





Full System Beam Quality Measurements



50 Hz, Full Power Beam Quality Measurements

$$M_x^2 = 2.5, M_y^2 = 2.5,$$







Temporal Characteristics




Oscillator Only: 16.5 ns




Oscillator + Preamp 1 + Preamp 2 : 19.5 ns



**Oscillator + Amp 1
+ Amp 2 : 20.9 ns**



**Full System:
Pulsewidth \sim 22 ns**



Final Design and Performance Summary



Parameter	Specification	Goal	Final Design/Performance
Pulse Energy (mJ)	900	1200	1040
M ²	NA	2	2.5
Laser head package	Single breadboard	NA	Single breadboard in custom enclosure
Cooling	Conductive to diodes and slabs	NA	Conductive to diodes and slabs
Seeding	Ramp & fire	NA	Ramp & fire
Electronics	Separate custom module	NA	Separate custom module



UV Wavelength Conversion



- The nonlinear optics based technology to efficiently generate UV wavelengths has been established using a flash lamp pumped Nd:YAG laser
- Utilizes a novel (Rotated Image Singly Resonant Twisted RectAngle) RISTRA OPO to generate 803 and 731.5 nm wavelengths from 532 nm pump
 - Two RISTRA OPOs are used stable and single mode 803 nm:
 - A small or low energy RISTRA OPO that is locked by Pound-Drever-Hall (PDH) technique and seeded by New Focus tunable diode laser operating at 803 nm
 - The big or high energy RISTRA OPO that is pulse seeded from the small OPO and locked by energy stabilization technique

State-of-the-art conversion efficiencies have been demonstrated

RISTRA OPO Module



- At 320 nm, >200 mJ extra-cavity SFG with good beam Quality
 - ▶ IR to UV efficiency > 21% (> 27% for 1 mJ seed)
- At 320 nm , up to 160 mJ intra-cavity SFG
 - ▶ IR to UV efficiency up to 24%
- Fluence $\leq 1 \text{ J/cm}^2$ for most beams




Image-rotating RISTRA Performance

-Spatial fluence profiles and pump depletion-





OPO signal
near-field
spatial fluence
profile, Fresnel
Number > 450




Flat pump profiles
have facilitated
high OPO
conversion with
good beam quality

Self-seeded
oscillation
in two-crystal
RISTRA
 $\sim 85\%$ pump
depletion




OPO signal
far-field spatial
fluence
profiles,
Fresnel
Number > 450


**Breadboard with electronics
and diagnostics used for
technology demonstration**




**PDH stabilized injection-seeder
OPO**




**Extensive diagnostics are utilized for characterization of
temporal and spatial profiles**



**Pulsed idler-seeded
803 nm OPO**




**Grating-tuned diode laser,
phase modulation and RF
electronics for PDH
stabilization**



Current Status




- Second harmonic generation efficiency (for pumping OPO and for SFG stage) exceeds 80%
- All components of 1576 nm pulsed idler-seeding system fully operational
 - Pound-Drever-Hall (PDH) stabilized RISTRA OPO
 - Sandia-built stabilization electronics
 - 1576 nm beam shaping optics and beam delivery optics
- 803 nm RISTRA OPO
 - Pulsed-idler seeded oscillation recently obtained
 - Frequency stabilization under construction
- Sum-frequency generation stage
 - All beam combining optics in place
 - LBO (12 mm x 12 mm x 40 mm) crystal for SFG stage to be delivered by 8/31



Current Status (Contd..)



- Method for pulsed injection seeding
 - Signal seed-pulse generated by backward pumping scheme replaced by idler pulse from separate small OPO
- Dimensions of 803 nm RISTRA OPO scaled up by factor of 1.5 to safely accommodate higher pulse energies
- To improve overall conversion efficiency
 - KTP crystals in OPO replaced by BBO in the big OPO
 - The small 803 nm diode seeded OPO is based on KTP
 - BBO crystal for SFG replaced by LBO for efficient conversion
- The UV converter scheme is being assembled on a 2' x 2' breadboard



Sub Tasks Nearing Completion




- Frequency stabilization of 803 nm OPO
 - Uses simple grazing incidence grating and split photodiode for feedback to control frequency of seeder OPO
- Sum-frequency generation stage
 - Requires delivery of LBO crystal
 - Final integration of all breadboard components
- Characterization of complete system on a 2' x 2' breadboard
 - Measure UV energy output and overall optical-to-optical conversion efficiency



Testing and Integration Efforts at NASA LaRC



- **Nd:YAG laser installation, testing and calibration complete**
 - Flat pump profiles from Nd:YAG laser achieved
- **SHG scheme to achieve 532 nm from 1064 nm established with >80% conversion efficiency**
- **Pump laser with UV converter setup integration**
 - Procurement of components for integration of the 1064 nm pump laser and UV converter complete
 - Small RISTRA OPO with a 803 nm diode assembled on a breadboard
 - Full integration will begin soon as soon as SFG module is ready



On Going and Future Work

Goal: To build fully Ozone functional DIAL System



Initial LRRP Goal



Nd:YAG pump Laser

**320 nm
UV Converter**

**308 nm
UV Converter**

**>200 mJ/pulse at
320 nm and 308 nm**

**Current Effort with
reduced Funding**




Nd:YAG pump Laser

**320 nm
UV Converter**

**>200 mJ/pulse
at 320 nm**

Accomplished

Near Term Goal



Nd:YAG pump Laser


**320 nm
UV Converter**

**308 nm
UV Converter**

**Telescope
+
Scanner**

**>60 mJ/pulse
at 320 nm and
308 nm**

Single pump laser based DIAL System: Components in yellow boxes will be built with additional resources



Summary and Conclusions



- All solid-state Nd:YAG pump laser development complete
 - The current laser design has been leveraged into other NASA and DOD programs
- Efficient high-pulse-energy UV generation technology has been demonstrated
 - **>200 mJ extra-cavity SFG; IR to UV efficiency > 21%**
 - **160 mJ intra-cavity SFG; IR to UV efficiency up to 24%**
- Custom designed opto-mechanical hardware for final prototype UV converter complete
- The system integration efforts at NASA LaRC is underway
- Current UV Transmitter effort is a technology demonstration with the hardware TRL = 3
 - Space qualifiable components have been used wherever possible
- The overall dimensions of the pump laser, associated electronics and UV converter setups can be reduced to less than 1/3rd their current sizes
- Solid-state UV Transmitter is amenable for space-worthy packaging